

Windows 8.1 installation guide.

1. Download OS from the link:
https://mega.nz/#!uk9mhbil!JQTCAaec2yZv4OdwVLM2oYAEmqN1N0jKbkz8_qIVMT8
2. Choose an empty USB drive, format it into FAT32 format.
3. Unzip the “zip” OS downloaded, and copy all folders and files into root directory.
4. Insert ready USB drive, If Model TC100, power on device, Press F7 to choose boot from USB. The OS installation will install automatically.
5. After installation, the device will power off automatically.
6. Power on device, it is ready for use.